

PARTS LIST

INDEX NO.	CODE NO.	PARTS NAMES
01-A	10027	NOSE PIECE(S) 2.4(3/32)
01-B	10028	NOSE PIECE(S) 3.2(1/8)
01-C	10029	NOSE PIECE(S) 4.0(5/32)
01-D	10030	NOSE PIECE(S) 4.8(3/16)
01	14450	SET OF 4 NOSE PIECES INCLUDES M-01-A, -B, -C, & -D.
02	10105	FRAME HEAD
03	10280	JAW CASE HEAD
04	10281	PAIR OF ULTRA JAWS (M)
05	10132	JAW PUSHER
06	10279	JAW CASE
07	10286	COLLAR FOR JAW CASE
08	10133	JAW PUSHER SPRING
09	10287	COLLAR SPRING
10	10148	LOCK WASHER
11	10113	JAW CASE LOCK NUT
12	10128	O-RING P-12
13	10129	BACK UP RING P-12
14U	14331	FRAME UNIT (INCLUDES 12 & 13)
15	12120	O-RING P-5
16	12135	BLEED PLUG
17	10109	OIL PISTON
18	10130	O-RING P-22A
19	10131	BACK UP RING P-22A
20A	10110	RETURN SPRING A (INNER)
20B	10111	RETURN SPRING B (OUTER)
20	14200	RETURN SPRING A + B (SET)
21	10153	O-RING S-26

INDEX NO.	CODE NO.	PARTS NAMES
22	10106	HANGER CLIP
23	10104	FRAME CAP
24	10015	SAFETY CAP (STANDARD)
25	10108	SAFETY CAP NUT
26-ST	10135	TRIGGER, SHORT
26-LT	13121	TRIGGER, LONG (OPTION)
27	10120	CONNECTOR
28	10119	TRIGGER LEVER
29-ST	10147	SPRING PIN 3×6
30-RJ	15812	AIR CYLINDER
31	10112	FRAME LOCK NUT
32	10144	SPRING PIN 3×22
33	10145	SPRING PIN 3×18
34	14154	SLOTTED PIN NOT REQUIRED
35	10149	O-RING P-7
36	12121	VALVE PUSHER
37-ST	10454	O-RING P-4
38	12132	VALVE PUSHER SPRING
39	10274	O-RING P-10
40-RJ	10441	VALVE SLEEVE
41	12120	O-RING P-5
42	10247	VALVE (STEEL BALL 8.0)
43-RJ	10444	VALVE SPRING
44	10152	O-RING S-14
45-RJ	14073	END PLUG
46	29736	BUMPER(RUBBER CUSHION)
47	14218	AIR PISTON UNIT
48	10134	O-RING P-60 (RUBBER CUSHION)

PARTS LIST

INDEX NO.	CODE NO.	PARTS NAMES
49	10080	O-RING G-70
50	14056	AIR CYLINDER CAP
51	14355	AIR SILENCER
52	14359	AIR SILENCER PLUG
53	10151	O-RING S-10
54	42479	DOUBLE MALE CONNECTOR
55	10149	O-RING P-7
56	42501	ROTARY JOINT
57	10285	RETAINING RING E-7
80	15820	DECAL, CAUTION
81	10141	SPANNER A
82	10218	SPANNER B
84	10140	AIR HOSE JOINT 1/4
85	10139	AIR HOSE JOINT NUT 1/4
86	10012	HYDRAULIC OIL
87	14142	PRIMING PUMP (INJECTOR)

EXPLODE VIEW AR-021M-RJ

