

## PNEUMATIC SCREWDRIVER MODEL NO.

SA-T10PB SA-T20PB SA-T30PB  
SA-T35PB SA-T38PB SA-T40PB  
SA-T45PB

No.	Part No.	Part Name	Q'ty	No.	Part No.	Part Name	Q'ty
1	5A3004	End Housing	1	31	6S2020	Valve Plate	1
2	7Q2005	O Ring	1	32	6S2004	Operating Rod	1
3	2P3000	Valve	1	33	6N2100	Cone Spring[T10 T20 T30 T35 T38]	1
4	7S2100	Set Screw And Washer	1	33-1	6N2101	Cone Spring[T40 T45]	1
5	2L3010	Switch	1	34	2P3019	Silencer[T10 T20]	1
6	7S2001	Ball Bearing	1	34-1	2P3020	Silencer[T30T35T38T40T45]	1
7	1S3001	End Plate	1	34-2	2Q5001	O Ring	1
8	6S2016	Pin	1	35	2S2001	Air Inlet Bushing [PT][T10 T20]	1
9	6S2013	Pin	2	35-1	2S2002	Air Inlet Bushing	1
10	1P3005	Cylinder	1	35-2	2S2001-A	Air Inlet Bushing [PS][T10 T20]	1
11	1S3040	10T Rotor [Model: T10 T20 T40]	1	35-3	2S3005	Air Inlet Bushing	1
11-1	1S3041	10T Rotor [Model: T45]	1	35-4	2S2003	Air Inlet Bushing [NPT][T10 T20]	1
12	1P3050	Blade	5	35-5	2S2004	Air Inlet Bushing	1
13	1P3060	Front Plate [T10 T20 T40 T45]	1	36	2S2103	Retainer	1
13-1	1P3065	Front Plate [T30 T35 T38]	1	37	7S2102	Ball	28
14	7S2002	Ball Bearing	1	38	3S2001	Pilot Pin	1
14-1	7S2007	Ball Bearing[T30 T35 T38]	1	39	3S2211	Rear Clutch	1
15	6N2020	C Ring [T10 T20 T40 T45]	1	40	6N2006	C Ring	1
16	1S3043	Rotor [T30 T35 T38]	1	41	3S2215	Center Clutch	1
18	1G6279	18T Main Gear [T30 T38]	1	42	7S2112	Ball	2
18-1	1G6280	21T Main Gear [T35]	1	43	3S2021	Anvil	1
19	1P2101	15T Plant Gear [T10 T20 T40]	4	44	7S2105	Ball	2
19-1	1P2110	12T Plant Gear [T30 T38]	4	45	6N2110	Spring	1
19-2	1P2102	10T Plant Gear [T35]	7	46	3S2226	Slide Base	1
19-3	1P2120	15T Plant Gear [T45]	4	47	3S2222	End Clutch	1
20	1P3280	Fifth Gear Cage [T10 T20 T40]	1	48	7S2102	Ball	22
20-1	1P3274	Third Gear Cage and Main Gear [T30 T38]	1	49	3S2231	Ball Race	1
20-2	1P6294	Third Gear Cage [T35]	1	50	6N3100	C Ring	1
20-3	1P2283	Fifth Gear Cage and Main Gear	1	51	6N3001	Torque Spring[T10]	1
21	1P2270	18T Main Gear [T10 T20]	1	51-1	6N3002	Torque Spring[T20]	1
21-1	1P2271	21T Main Gear [T35]	1	51-2	6N3013	Torque Spring[T30]	1
21-2	1P2090	14T Main Gear [T40]	1	51-3	6N5008	Torque Spring[T35]	1
22	1P2110	12T Plant Gear [T10 T20 T30 T38]	4	51-4	6N3004	Torque Spring[T38 T40]	1
22-1	1P2102	10T Plant Gear [T35]	7	51-5	6N3005	Torque Spring[T45]	1
22-2	1P2130	14T Plant Gear [T40]	4	52	2S2120	Washer	1
22-3	1P2121	15T Plant Gear [T45]	4	53	3S2245	Anvil Bushing	1
23	1P2284	Third Gear Cage [T10 T20 T30 T38]	1	54	3A2201	Clutch Housing	1
23-1	1P6297	Third Gear Cage [T35]	1	55	6S2011	Needle Pin[T10 T30 T40 T45]	3
23-2	1P2285	Fourth Gear Cage [T40]	1	55-1	6S2010	Needle Pin[T20 T35 T38]	3
23-3	1P2286	Fifth Gear Cage [T45]	1	56	3S3101	Regulation Washer	1
24	1S2061	Internal Gear	1	57	3A3031	Torque Ring	1
25	5A3010	Center Housing	1	58	6N2003	Spring	1
26	7S5003	Ball Bearing	1	59	7S3107	Ball	1
27	7Q2015	O Ring	1	60	5S2001	Bit Slide Sleeve	1
28	2P3011	Silencer[T10 T20]	2	61	6N2001	C Ring	1
28-1	2P3010	Silencer[T30T35T38T40]	2	62	5A3020	Rear Housing	1
28-2	2P3010	Silencer[T45]	1	63	2U2002	Air House Nipple	1
28-3	2S2104	Washer [T45]	1	64	5N2001	Suspension Ring	1
29	2A3001	Exhaust Deflector	1	65	5L3010	Soft Cover [Black]	1
30	7Q2007	O Ring	1	66	5L2023	Color Ring	1

# PNEUMATIC SCREWDRIVER MODEL NO.

SA-T10PB SA-T20PB SA-T30PB  
SA-T35PB SA-T38PB SA-T40PB  
SA-T45PB

