
1/2" SUPER HYBRID RATCHET



| Index No. | Parts No. | Description | Qty. Per tool |
|-----------|------------|----------------------|------------------|
| 1 | 7700SHR-01 | Clutch Sleeve | 1 |
| 2 | 7700SHR-02 | Ball Bearing | 2 |
| 3 | 7700SHR-03 | Spacer | 1 |
| 4 | 7700SHR-04 | Anvil Shank | 1 |
| 5 | 7700SHR-05 | Cam Release Spring | 1 |
| 6 | 7700SHR-06 | Hammer | 2 |
| 7 | 7700SHR-07 | Cam | 1 |
| 8 | 7700SHR-08 | Cam Ball | 1 |
| 9 | 7700SHR-09 | Cam Ball Pilot | 1 |
| 10 | 7700SHR-10 | Hammer Cage | 1 |
| 11 | 7700SHR-11 | Ball Bearing | 1 |
| 12 | 7700SHR-12 | Lock Spacer | 1 |
| 13 | 7700SHR-13 | Planat Cage | 1 |
| 14 | 7700SHR-14 | Planet Pin | 2 |
| 15 | 7700SHR-15 | Planet Gear | 2 |
| 16 | 7700SHR-16 | Internal Gear | 1 |
| 17 | 7700SHR-17 | Washer | 1 |
| 18 | 7700SHR-18 | Ball Bearing | 1 |
| 19 | 7700SHR-19 | Front End Plate | 1 |
| 20 | 7700SHR-20 | Rotor | 1 |
| 21 | 7700SHR-21 | Rotor Blade | 4 |
| 22 | 7700SHR-22 | Cylinder | 1 |
| 23 | 7700SHR-23 | Rear End Plate | 1 |
| 24 | 7700SHR-24 | Spring Pin | 4 |
| 25 | 7700SHR-25 | Ball Bearing | 1 |
| 26 | 7700SHR-26 | Motor Housing | 1 |
| 27 | 7700SHR-27 | Ring | 1 |
| 28 | 7700SHR-28 | Housing Cover | 1 |
| 29 | 7700SHR-29 | O-Ring | 1 |
| 30 | 7700SHR-30 | Exhaust Sleeve | 1 |
| 31 | 7700SHR-31 | O-Ring | 1 |
| 32 | 7700SHR-32 | Swivel Inlet Bushing | 1 |
| 33 | 7700SHR-33 | Regulator Dial | 1 |
| 34 | 7700SHR-34 | O-Ring | 1 |
| 35 | 7700SHR-35 | Valve Spring | 1 |
| 36 | 7700SHR-36 | Throttle Valve | 1 |

| Index No. | Parts No. | Description | Qty. Per tool |
|-----------|------------|---------------------|------------------|
| 37 | 7700SHR-37 | O-Ring | 1 |
| 38 | 7700SHR-38 | O-Ring | 2 |
| 39 | 7700SHR-39 | O-Ring | 1 |
| 40 | 7700SHR-40 | Spring Pin | 1 |
| 41 | 7700SHR-41 | Air Regulator | 1 |
| 42 | 7700SHR-42 | Valve Shaft | 1 |
| 43 | 7700SHR-43 | Spring Pin | 1 |
| 44 | 7700SHR-44 | Throttle Lever | 1 |
| 45 | 7700SHR-45 | Clamp Nut | 1 |
| 46 | 7700SHR-46 | Ball Bearing | 2 |
| 47 | 7700SHR-47 | Crank Shaft | 1 |
| 48 | 7700SHR-48 | Reverse Switch | 1 |
| 49 | 7700SHR-49 | Torx Head Screw | 1 |
| 50 | 7700SHR-50 | Pivot Post | 1 |
| 51 | 7700SHR-51 | Soc. Head Cap Screw | 2 |
| 52 | 7700SHR-52 | Steel Housing | 1 |
| 53 | 7700SHR-53 | Bushing | 1 |
| 54 | 7700SHR-54 | Friction Washer | 1 |
| 55 | 7700SHR-55 | Belleville Washer | 1 |
| 56 | 7700SHR-56 | Square Drive Assy. | 1 |
| 57 | 7700SHR-57 | Wear Plate | 1 |
| 58 | 7700SHR-58 | Spring | 1 |
| 59 | 7700SHR-59 | Reverse Cam | 1 |
| 60 | 7700SHR-60 | Dowel Pin | 2 |
| 61 | 7700SHR-61 | Drive Link | 1 |
| 62 | 7700SHR-62 | Torsion Spring | 1 |
| 63 | 7700SHR-63 | Pawl (Double) | 1 |
| 64 | 7700SHR-64 | Pawl (Single) | 1 |
| 65 | 7700SHR-65 | Drive Bushing | 1 |
| 66 | 7700SHR-66 | Cover Plate | 1 |
| 67 | 7700SHR-67 | Washer | 1 |
| 68 | 7700SHR-68 | Button Head Screw | 1 |
| 69 | 7700SHR-69 | Grease Fitting | 1 |
| | | | |
| | | | |
| | | | |