

# PARTS LIST

INDEX NO.	CODE NO.	PARTS NAME
01-A	10213	NOSE PIECE (M) 2.4 (3/32")
01-B	10214	NOSE PIECE (M) 3.2 (1/8")
01-C	10215	NOSE PIECE (M) 4.0 (5/32")
01-D	14350	NOSE PIECE (M) 4.8 (3/16")
01-F	10226	NOSE PIECE (H) 6.4 (1/4")
01	15169	SET OF 5 NOSE PIECES INCLUDES 01-A, 01-B, 01-C, 01-D & 01-F
02	10191	FRAME HEAD
03	14378	JAW CASE HEAD (M)
03-A	10447	JAW CASE HEAD (H)
04	10281	A PAIR OF ULTRA JAWS (M)
04-A	10493	A PAIR OF ULTRA JAWS (H)
05	10209	JAW PUSHER (M)
05-A	10224	JAW PUSHER (H)
06	10429	JAW CASE
07	10448	COLLAR FOR JAW CASE
08	10210	JAW PUSHER SPRING
09	10449	COLLAR SPRING
10	10148	LOCK WASHER
11	10113	JAW CASE LOCK NUT
12	10128	O-RING (P-12)
13	10129	BACK-UP RING (P-12)
14U	14392	FRAME UNIT (INCLUDES 12 & 13)
15	12120	O-RING (P-5)
16	12135	BLEED PLUG
17	10195	OIL PISTON
18	10207	O-RING (P-24)
19	10208	BACK-UP RING (P-24)

INDEX NO.	CODE NO.	PARTS NAME
20A	10196	RETURN SPRING 'A' (INNER)
20B	10197	RETURN SPRING 'B' (OUTER)
20	14139	RETURN SPRING A+B (SET)
21	10221	O-RING (S-28)
22	10192	HANGER CLIP
23	10190	FRAME CAP
24	10072	SAFETY CAP (STANDARD)
25	10194	SAFETY CAP NUT
26-ST	10135	TRIGGER, SHORT
26LT	13126	TRIGGER, LONG (OPTION)
27	10202	CONNECTOR
28	10119	TRIGGER LEVER
29-ST	10147	SPRING PIN (3×6mm)
30-RJ	15832	AIR CYLINDER
31	10112	FRAME LOCK NUT
32	10144	SPRING PIN (3×22mm)
33	10145	SPRING PIN (3×18mm)
34	14154	SLOTTED PIN (4×31mm)
35	10219	O-RING (P-9)
36	14435	VALVE PUSHER
37-ST	12120	O-RING (P-5)
38	10453	VALVE PUSHER SPRING
39	10274	O-RING (P-10)
40-RJ	10441	VALVE SLEEVE
41	12120	O-RING (P-5)
42	10247	VALVE (STEEL BALL 8.0φmm)
43-RJ	10444	VALVE SPRING
44	10152	O-RING (S-14)

## PARTS LIST

INDEX NO.	CODE NO.	PARTS NAME
45RJ	14073	END PLUG
46	10212	O-RING (P-70)
47	14365	AIR PISTON UNIT (INCLUDES 48 BUMPER)
48	10114	BUMPER (RUBBER CUSHION)
49	10211	O-RING (G-80)
50	14427	AIR CYLINDER CAP
51	14355	SILENCER
52	14359	PLUG
53	10151	O-RING (S-10)
54	12130	DOUBLE MALE CONNECTOR
55	10149	O-RING (P-7)
56	10294	ROTARY JOINT
57	10285	E-RETAINING RING
80	15905	DECAL, CAUTION
81	10217	SPANNER 'A'
82	10218	SPANNER 'B'
83	10143	CLEANING BRUSH
84	10140	AIR HOSE JOINT 1/4"
85	10139	AIR HOSE JOINT NUT 1/4"
86	10012	HYDRAULIC OIL
87	14142	PRING PUMP

